



CONSOLE VAULT®

INNOVATIVE SECURITY SOLUTIONS

(800) 878-1369

www.consolevault.com

2020+ — Subaru Outback Instruction Sheet (1124)



Installation Steps:

- 1) If applicable, reset the combination lock before beginning installation.
- 2) Remove all contents from the center console.
- 3) Leave pad at the bottom of the safe and gently slide it into the console (1).
- 4) Insert both self drilling screws by hand, then using a 7/16" socket wrench, complete tightening until the screw heads fully contact the insert nuts and **STOP! (2) Warning! Overtightening the screws will cause damage to the threads.**
- 5) The installation is now complete!

